




The PT1DN communicates to your PLC over DeviceNET<sup>®</sup> and provides a precision position feedback signal for full-scale measurement ranges from 2 to 50 inches. Because the PT1DN uses a potentiometer as its sensing element, the position signal is "absolute" and does not have to be reset to a "home" position upon startup.

The PT1DN is part of our compact line of cableextension transducers and is perfect where space is limited.



## PT1DN **Cable Actuated Sensor** Industrial Grade DeviceNET<sup>®</sup> Communication

Absolute Linear Position to 50 inches (1270 mm) **Aluminum and Polycarbonate Enclosure Compact Design IP65 • NEMA 4 Protection** 

### General

Full Stroke Range	0-2 to 0-50 inches
Electrical Interface	CANbus ISO 11898
Protocol	DeviceNET version 2.0
Accuracy	$\pm$ 0.25% to $\pm$ 0.10% full stroke (see ordering information)
Repeatability	± 0.02% full stroke
Resolution	± 0.003% full stroke
Measuring Cable	.019-in. dia. nylon-coated stainless steel
Enclosure	glass-filled polycarbonate and black anodized aluminum
Sensor	plastic-hybrid precision potentiometer
Potentiometer Cycle Life	see ordering information
Maximum Retraction Acceleration	see ordering information
Weight	1 lb. max.


## **Electrical**

Input Voltage	bus powered
Input Current	40 mA
Address Setting/Node ID	063 set via DIP switches (default setting: 63)
Baud Rate	125K, 250K or 500K set via DIP switches
EDS File	available @ http://www.celeso.com/download

## **Environmental**

Environmental Suitability	NEMA 4, IP 67
<b>Operating Temperature</b>	0° to 185°F (-17° to 85°C)
Vibration	up to 10 g to 2000 Hz maximum

## I/O Format



#### \*Current Measurement Count

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes ( $B_0$  and  $B_1$ ) of the data field.  $B_0$  is the LSB (least significant byte) and  $B_1$  is the MSB (most significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

#### \*\*Full Stroke Range

The Full Stroke Range (FSR) is a 16-bit value in the data field that expresses the full range of the sensor in inches. This value can be used to convert the actual count to units of measurement should the application require it.

The full stroke measurement range occupies the second two bytes  $(B_2 \text{ and } B_3)$  of the data field.

 $B_2$  is the LSB (least significant byte) and  $B_3$  is the MSB (most significant byte).

This value is expressed in inches.

#### Example:

Hex Value	Decimal Equivalent	Full Stroke Range
001E	30	30 inches

#### **Converting CMC to Inches**

If required, the CMC can easily be converted to a linear measurement expressed in inches instead of just counts.

This is accomplished by first dividing the CMC by 65,535 (total counts over the range) and then multiplying that value by the FSR:

$$\left(\frac{CMC}{65,535}\right)$$
 X FSR

#### Example:

If the full stroke range is **30 inches** and the current position is **OFF2 Hex** (4082 Decimal) then,



#### Address Setting (Node ID), Baud Rate and Bus Termination Settings

#### Address Setting (Node ID)


The Address Setting (Node ID) is set via 6 switches located on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.

The DIP switch settings are binary starting with switch number 1 (=  $2^{0}$ ) and ending with switch number 6 (=  $2^{5}$ ).

DIP-1 (2 <sup>0</sup> )	DIP-2 (2 <sup>1</sup> )	DIP-3 (2 <sup>2</sup> )	<b>DIP-4</b> (2 <sup>3</sup> )	DIP-5 (2 <sup>4</sup> )	DIP-6 (2 <sup>5</sup> )	<i>address</i> (decimal)
0	0	0	0	0	0	0
1	0	0	0	0	0	1
0	1	0	0	0	0	2
•••			•••	•••		•••
1	1	1	1	1	1	63




#### DeviceNET Controller Board and DIP Switch Location



Baud Rate

The transmission baud rate may be either factory preset at the time of order or set manually at the time of installation.

The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.



#### **Bus Termination**


The setting of the internal bus termination resistor may be specified upon order or manually changed by the end user at the time of installation.

The bus termination resistor is activated setting switches 1 & 2 on the 2-pole DIP switch (located on the internal DeviceNET controller board) to the "ON" position.




#### = "ON" (resistor active)

= "OFF" (resistor not active)




## **Outline Drawing**



DIMENSIONS ARE IN INCHES [MM] tolerances are 0.03 IN. [0.5 MM] unless otherwise noted.



#### Model Number:



Sample Model Number:

• electrical connection:

# PT1DN - 30 - UP - SG - 500 - TR - SC5 Image: 30 inches Image: 30 inches Image: up Image: spring-loaded guide Image: 500 k bits/sec. Image: 500 k bits/sec. Image: yes

\* tolerance = +.005 -.001 [+.13 -.03]


\*\* tolerance = +.005 -.005 [+.13 -.13]

5 meter cordset with straight plug


## Ordering Information (cont.)

Full Stroke Rang	je:								
<u>     order code:</u>	2	5	10	15	20	25	30	40	50
full stroke range, min:	2 in.	5 in.	10 in.	15 in.	20 in.	25 in.	30 in.	40 in.	50 in.
accuracy (% of f.s.):	0.2	5%		0.1	.5%			0.10%	
potentiometer cycle life:	2,500,00	0 cycles		500,000	0 cycles			250,000 cycles	;
cable tension (20%):	12 oz.	5 oz.	12 oz.	9 oz.	б oz.	5 oz.	9 oz.	6 oz.	5 oz.
max. cable acceleration:	11 g	3 g	11 g	5 g	4 g	3 g	5 g	4 g	3 g

#### Cable Exit:



#### **Cable Guide:**



\*note: start of full stroke range begins at full compression point (except 2-inch and 5-inch ranges).

Baud Rate:			
<b>G</b> order code:	125	250	500
	125 kbaud	250 kbaud	500 kbaud

#### **Terminating Resistor:**

 O order code:
 TR
 NR

 terminating resistor
 no terminating resistor

#### **Electrical Connection:**

