




The PT5CN cable extension position transducer communicates linear position via the CANbus SAE J1939 interface providing a precision position feedback to your PLC. The PT5DN is offered in full stroke ranges up to 250 inches and a thermoplastic measuring cable for high cycle and rugged applications.

Because the PT5CN uses a potentiometer as its sensing element, the position signal is "absolute" and does not have to be reset to a "home" position upon startup.

Output Signal



PT5CN

Cable Actuated Sensor CANbus • SAE J1939 Output Signal

Absolute Linear Position to 250 inches (6350 mm)

Hard Anodized Aluminum Enclosure

High Cycle Applications

IP67 • NEMA 6 Protection

General

Full Stroke Ranges 0-10 to 0-250 inches
Electrical Interface CANbus SAE J1939

Protocol Proprietary B

Accuracy $\pm 0.25\%$ to $\pm 0.10\%$ full stroke (see ordering info)

Repeatability $\pm 0.02\%$ full stroke (see ordering info)

Resolution ± 0.003% full stroke

Measuring Cable stainless steel or thermoplastic

Enclosure Material hard anodized aluminum

Sensor plastic-hybrid precision potentiometer

Potentiometer Cycle see ordering information

Life

Maximum Retraction

Acceleration

see ordering information

Weight 5 lbs. max.

Electrical

Input Voltage 7 - 18 VDC
Input Current 60 mA max.

Baud Rate 125K, 250K, or 500K via DIP switches
Update Rate 10 ms. (20 ms. available–contact factory)

Environmental

Environmental NEMA 4/6, IP 65/67


Suitability

Operating Temperature -40° to 185°F (-40° to 85°C)

Vibration up to 10 g to 2000 Hz maximum

SENSOR SOLUTIONS /// PT5CN 12//2015 Page 1

I/O Format and Settings



repetition = 8 msec.

Identifier

Message Priority Fur			Fut U:	ure se					Reference ietary B				Data Field Type*					Not Used			N	Node ID**							
Example –	1	0	0	0	0	1	1	1	1	1	1	1	1	0	1	0	1	0	0	1	1	0	0	1	1	1	1	1	1
Identifier Bit No. –	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Hex Value –		0			F	:		F				5				3			3			F							

^{*}Sensor field data can be factory set to customer specific value. **Customer defined, set via Dips 1-6. Bit values shown for example only, see Address Setting below.

Data Field

 B_0 = LSB current % of measurement range byte B_1 = MSB current % of measurement range byte

B₂ = LSB current measurement count byte
 B₃ = MSB current measurement count byte

B₄ = error flag **B**₅ = error flag

B₆ = LSB velocity data byte
 B₇ = MSB velocity data byte

Velocit	ty Data	Error	Flags	Measu	rent rement unt		t % of rement nge	
B ₇	B ₆	B ₅	B ₄	B ₃	B ₂	B ₁	Bo	

B-7	B ₆	Be	B ₄	Ba	B ₂	В.	Bo	

Current Measurement Count

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable. The CMC is a 16-bit value that occupies bytes B₂ and B₃ of the data field. B₂ is the LSB (least significant byte) and B₃ is the MSB (most significant byte).

The **CMC** starts at **0x0000** with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at **0xFFFF**. This holds true for all ranges.

Converting CMC to Linear Measurement

To convert the current measurment count to inches or millimeters, simply divide the count by 65,535 (total counts over the range) and then multiply that value by the full stroke range:

$$\left(\frac{\text{current measurement}}{\text{count}}\right) X \text{ full stroke} \\ \hline 65.535 X \text{ range}$$

Sample Conversion:

If the full stroke range is **30 inches** and the current position is **0x0FF2** (4082 Decimal) then,

$$\left(\frac{4082}{65.535}\right)$$
 X 30.00 inches = 1.87 inches

If the full stroke range is **625 mm** and the current position is **0x0FF2** (4082 Decimal) then,

$$\left(\frac{4082}{65,535}\right)$$
 X 625 mm = 39 mm

B₇ B₆ B₅ B₄ B₃ B₂ B₁ B₀

Current % of Measurement Range

The Current % of Measurement Range is a 2-byte value that expresses the current linear position as a percentage of the entire full stroke range. Resolution is .1 % of the full stroke measurement range.

This value starts at **0x0000** at the beginning of the stroke and ends at **0x03E8**.

Example:

Hex	Decimal	Percent
0000	0000	0.0%
0001	0001	0.1%
0002	0002	0.2%
03E8	1000	100.0%



Error Flags

0x55 (yellow LED on controller board) indicates that the sensor has begun to travel beyond the calibrated range of the internal position potentiometer.


OxAA (red LED on controller board) indicates that the sensor has moved well beyond the calibrated range of the internal position potentiometer.

If either error flag occurs within the full stroke range of the sensor, the unit should be returned to the factory for repair and recalibration.

Velocity

Data in bytes ${\bf B_7}$ - ${\bf B_6}$ is the change in the CMC (current measurement count) over a 100 msec time period. This data can then be used to calculate velocity in a post processing operation.

B₇ B₆ B₅ B₄ B₃ B₂ B₁ B₀



Velocity Calculation



Sample Calculations

Cable Extension (positive direction):

 $B_7 - B_6 = 0x89C6$ (43462 Dec), full stroke = 60 in.

$$\left(\frac{35270-32767}{.1 \text{ sec}}\right) \times \left(\frac{60 \text{ in.}}{65,535}\right) = 22.92 \text{ in. / sec.}$$

Cable Retraction (negative direction):

 $B_7 - B_6 = 0x61A8$ (25000 Dec), full stroke = 60 in.

$$\left(\frac{25000-32767}{.1 \text{ sec}}\right) \chi \left(\frac{60 \text{ in.}}{65,535}\right) = -71.11 \text{ in. / sec.}$$

Setting the Address (Node ID) and Baud Rate

Address Setting (Node ID)

The Address Setting (Node ID) is set via 6 switches located on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.

The DIP switch settings are binary starting with switch number 1 (= 20) and ending with switch number $6 (= 2^5)$.

Baud Rate

The transmission baud rate may be either factory preset at the time of order or set manually at the time of installation.

The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.

DIP-8


0

0

DIP-7


1

CANBus Controller Board



internal dip switches & controller board


to gain access to the controller board, remove four Allen-Head Screws and remove end cover bracket.





Caution! Do Not Remove Spring-Side End Cover removing spring-side end cover could cause spring to become unseated and permanently damaged.

DIP-1 DIP-2 DIP-3 DIP-4 DIP-5 DIP-6 address (2^{0}) (2^1) (2^2) (2^3) (2^4) (2^5) (decimal) 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 2 ... 1 1 1 63




baud rate

125k


250k

Outline Drawing




A	DIMENSION	(inches[mm])
	N34	S47 & V/62

N34	S47 & V62
measuring cable	measuring cable
0.05 [1,2]	0.08 [2,0]
0.07 [1,8]	0.12 [3,0]
0.09 [2,4]	0.16 [3,9]
0.14 [3,5]	0.23 [5,9]
0.19 [4,7]	0.31 [7,9]
0.23 [5,9]	0.39 [9,9]
0.28 [7,0]	0.47 [11,8]
0.37 [9,4]	0.62 [15,8]
0.46 [11,7]	0.78 [19,7]
0.58 [14,7]	0.97 [24,7]
0.69 [17,6]	1.16 [29,6]
0.92 [23,5]	n/a
1.16 [29,3]	n/a
	measuring cable 0.05 [1,2] 0.07 [1,8] 0.09 [2,4] 0.14 [3,5] 0.19 [4,7] 0.23 [5,9] 0.28 [7,0] 0.37 [9,4] 0.46 [11,7] 0.58 [14,7] 0.69 [17,6] 0.92 [23,5]



DIMENSIONS ARE IN INCHES [MM] tolerances are 0.03 IN. [0.5 MM] unless otherwise noted.



- * tolerance = +.005 -.001 [+.13 -.03]
- ** tolerance = +.005 -.005 [+.13 -.13]

Ordering Information

Model Number:



Sample Model Number:

PT5CN - 50S47FR - J50032SC5

measuring cable:

(50 inches) (.047 bare stainless) **S47** FR (front) measuring cable exit: interface:

4 B O O baud rate: node ID:

(CANbus SAE J1939) 500 (500k bits/sec.) 32 (32 decimal)


electrical connection: SC5 (5-meter cordset with straight plug)

Full Stroke Range:


® order code:	10	15	20	25	30	40	50	60	80	100	125	150	200	250	
full stroke range, min:	10 in.	15 in.	20 in.	25 in.	30 in.	40 in.	50 in.	60 in.	80 in.	100 in.	125 in.	150 in.	200 in.	250 in.	
accuracy (±% of f.s.):	.75%	.6%	.5%	.5%	.5%	.3%	.3%	.25%	.25%	.25%	.25%	.18%	.18%	.18%	
repeatability (±% of f.s.):	.1%	.1%	.05%	.05%	.05%	.05%	.05%	.02%	.02%	.02%	.02%	.02%	.02%	.02%	
potentiometer cycle life:		2,50	0,000 cy	cles		500,000 cycles						250,000 cycles			
cable tension (20%):		41 ounces											21 o	unces	
k. cable velocity/acceleration:		300 in./sec ● 5 g											120 in./s	sec • 2 g	

Measuring Cable:

max.




Cable Exit:



Baud Rate:




Node ID:



select address (0 - 63 Decimal)

Electrical Connection:



SENSOR SOLUTIONS /// PT5CN 12//2015 Page 5